

SAW Resonators Part Number System

Type	Nominal Frequency (MHz)	Operating Temperature Range	Frequency Tolerance	Option (can be blank)
S18 SR2016 SR1814 S22 S51 D02 D01	Enter the nominal frequency (6 digits after dot)	G= -40°C to +85°C H= -40°C to +105°C J= -55°C to +125°C X= Others	50= ±50KHz 75= ±75KHz 100= ±100KHz (Enter the value of frequency tolerance)	Blank = Standard R = Tape and Reel X = Additional Specifications